CSCI-1680 Wireless

Rodrigo Fonseca



Wireless

Today: wireless networking truly ubiquitous

- 802.11, 3G, (4G), WiMAX, Bluetooth, RFID, ...
- Sensor networks, Internet of Things
- Some new computers have no wired networking
- 4B cellphone subscribers vs. 1B computers
- What's behind the scenes?



Wireless is different

- Signals sent by the sender don't always reach the receiver intact
 - Varies with space: attenuation, multipath
 - Varies with time: conditions change, interference, mobility
- Distributed: sender doesn't know what happens at receiver
- Wireless medium is inherently shared
 - No easy way out with switches



Implications

- Different mechanisms needed
- Physical layer
 - Different knobs: antennas, transmission power, encodings
- Link Layer
 - Distributed medium access protocols
 - Topology awareness
- Network, Transport Layers
 - Routing, forwarding
- Most advances do not abstract away the physical and link layers



Physical Layer

Specifies physical medium

- Ethernet: Category 5 cable, 8 wires, twisted pair, R45 jack
- WiFi wireless: 2.4GHz

Specifies the signal

- 100BASE-TX: NRZI + MLT-3 encoding
- 802.11b: binary and quadrature phase shift keying (BPSK/QPSK)

Specifies the bits

- 100BASE-TX: 4B5B encoding
- 802.11b @ 1-2Mbps: Barker code (1bit -> 11chips)





What can happen to signals?

Attenuation

- Signal power attenuates by ~r² factor for omni-directional antennas in free-space
- Exponent depends on type and placement of antennas
 - < 2 for directional antennas

• > 2 if antennas are close to the ground







Interference

External sources

- E.g., 2.4GHz unlicensed ISM band
- -802.11
- 802.15.4 (ZigBee), 802.15.1 (Bluetooth)
- 2.4GHz phones
- Microwave ovens

Internal sources


- Nodes in the same network/protocol can (and do) interfere


Multipath

Self-interference (destructive)



Multipath





• May cause attenuation, destructive interference



Wireless Modulation/Encoding

- More complex than wired
- Modulation, Encoding, Frequency
 - Frequency: number of symbols per second
 - Modulation: number of chips per symbol
 - E.g., different phase, frequency, amplitude
 - Encoding: number of chips per bit (to counter errors)

Example

- 802.11b, 1Msps: 11Mcps, DBPSK, Barker Code
 - 1 chip per symbol, 11 chips/bit
- 802.11b, 2Msps: 22Mcps, DQPSK, Barker Code
 - 2 chips per symbol, 11 chips/bit




Link Layer

- Medium Access Control
 - Should give 100% if one user
 - Should be efficient and fair if more users
- Ethernet uses CSMA/CD
 - Can we use CD here?
- No! Collision happens at the receiver
- Protocols try to avoid collision in the first place




Hidden Terminals



- A can hear B and C
- B and C can't hear each other
- They both interfere at A
- B is a hidden terminal to C, and vice-versa
- Carrier sense at sender is useless



Exposed Terminals



- A transmits to B
- C hears the transmission, backs off, even though D would hear C
- C is an exposed terminal to A's transmission
- Why is it still useful for C to do CS?



Key points

- No global view of collision
 - Different receivers hear different senders
 - Different senders reach different receivers
- Collisions happen at the receiver
- Goals of a MAC protocol
 - Detect if receiver can hear sender
 - Tell senders who might interfere with receiver to shut up




Simple MAC: CSMA/CA

- Maintain a waiting counter c
- For each time channel is free, c--
- Transmit when c = 0
- When a collision is inferred, retransmit with exponential backoff
 - Use lack of ACK from receiver to infer collision
 - Collisions are expensive: only full packet transmissions
- How would we get ACKs if we didn't do carrier sense?




- Idea: transmitter can check availability of channel at receiver
- Before every transmission
 - Sender sends an RTS (Request-to-Send)
 - Contains length of data (in *time* units)
 - Receiver sends a CTS (Clear-to-Send)
 - Sender sends data
 - Receiver sends ACK after transmission
- If you don't hear a CTS, assume collision
- If you hear a CTS for someone else, shut up
















Benefits of RTS/CTS

- Solves hidden terminal problem
- Does it?
 - Control frames can still collide
 - E.g., can cause CTS to be lost
 - In practice: reduces hidden terminal problem on data packets



Drawbacks of RTS/CTS

- Overhead is too large for small packets
 - 3 packets per packet: RTS/CTS/Data (4-22% for 802.11b)
- RTS still goes through CSMA: can be lost
- CTS loss causes lengthy retries
- 33% of IP packets are TCP ACKs
- In practice, WiFi doesn't use RTS/CTS



Other MAC Strategies

Time Division Multiplexing (TDMA)


- Central controller allocates a time slot for each sender
- May be inefficient when not everyone sending

Frequency Division

- Multiplexing two networks on same space
- Nodes with two radios (think graph coloring)
- Different frequency for upload and download



ISM Band Channels





Network Layer

- What about the network topology?
- Almost everything you use is single hop!
 - 802.11 in infrastructure mode
 - Bluetooth
 - Cellular networks
 - WiMax (Some 4G networks)
- Why?
 - Really hard to make multihop wireless efficient



WiFi Distribution System

- 802.11 typically works in infrastructure mode
 - Access points fixed nodes on wired network
- Distribution system connects Aps
 - Typically connect to the same Ethernet, use learning bridge to route to nodes' MAC addresses

Association

- Node negotiates with AP to get access
- Security negotiated as well (WEP, WPA, etc)
- Passive or active



Wireless Multi-Hop Networks

Some networks are multihop, though!

- Ad-hoc networks for emergency areas
- Vehicular Networks
- Sensor Networks
 - E.g., infrastructure monitoring
- Multihop networking to share Internet access
 - E.g. Meraki




Many Challenges

- Routing
 - Link estimation
- Multihop throughput dropoff



The Routing Problem



- Find a route from S to D
- Topology can be very dynamic



Routing

- Routing in ad-hoc networks has had a lot of research
 - General problem: any-to-any routing
 - Simplified versions: any-to-one (base station), one-toany (dissemination)
- DV too brittle: inconsistencies can cause loops
- DSDV
 - Destination Sequenced Distance Vector



Many Others

- DSR, AODV: on-demand
- Geographic routing: use nodes' physical location and do greedy routing
- Virtual coordinates: derive coordinates from topology, use greedy routing
- Tree-based routing with on-demand shortcuts
- •



Routing Metrics

- How to choose between routes?
- Hopcount is a poor metric!
 - Paths with few hops may use long, marginal links
 - Must find a balance
- All links do local retransmissions
- Idea: use expected transmissions over a link as its cost!
 - ETX = 1/(PRR) (Packet Reception Rate)
 - Variation: ETT, takes data rate into account



Multihop Throughput

- Only every third node can transmit!
 - Assuming a node can talk to its immediate neighbors
 - (1) Nodes can't send and receive at the same time
 - (2) Third hop transmission prevents second hop from receiving
 - (3) Worse if you are doing link-local ACKs
- In TCP, problem is worse as data and ACK packets contend for the channel!
- Not to mention multiple crossing flows!



Sometimes you can't (or shouldn't) hide that you are on wireless!

• Three examples of relaxing the layering abstraction



Examples of Breaking Abstractions


TCP over wireless

- Packet losses have a strong impact on TCP performance
- Snoop TCP: hide retransmissions from TCP end-points
- Distinguish congestion from wireless losses



4B Link Estimator


• Uses information from Physical, Routing, and Forwarding layers to help estimate link quality





Stanford's Full Duplex Wireless

- Status quo: nodes can't transmit and receive at the same time
 - Why? TX energy much stronger than RX energy
- Key insight:






• With other tricks, 92% of optimal bandwidth

Backscatter

- Transmit without generating signals!
 - Don't transmit, reflect!
- Flashlight and mirror analogy





Backscatter

Ambient Backscatter

Wi-Fi Backscatter Passive Wi-Fi

- Reflect ambient TV signals
- Communicate
 b/w battery-free
 devices
- SIG'13: 100 bps-1 kbps @ upto 10 feet
- SIG'14: 10 kbps-1Mbps @ up to 80 feet

- Communicate with COTS Wi-Fi clients
- Encode data using variations in the Wi-Fi channel
- SIG'14: 100 bps-10kbps @ 10 feet

- Communicate with unmodified Wi-Fi clients
- Create 802.11b
 Wi-Fi packets
 using reflections
- NSDI'16: 1-11
 Mbps @ 100 feet



Summary

- Wireless presents many challenges
 - Across all layers
 - Encoding/Modulation (we're doing pretty well here)
 - Distributed multiple access problem
 - Multihop
- Most current protocols sufficient, given over provisioning (good enough syndrome)
- Other challenges
 - Smooth handoff between technologies (3G, Wifi, 4G...)
 - Low-cost, long range wireless for developing regions
 - Energy usage

